

Ultra 550 LCD/Keyboard Mount



Model Number as shown:
UL550-W3-KPP-A2-QG

(monitor, keyboard and mouse not included)

ICW

Ultra 550 LCD/Keyboard Mount

DESCRIPTION:

The Ultra 550 LCD arm with Paralink interface allows the full articulation of the LCD and keyboard. It extends 46.1" from the mount to the tip of the keyboard tray. It folds up tightly against the wall when not in use. A knob next to the monitor tightens it into position. The monitor can be adjusted 5" vertically on the slide rail. The keyboard height is a one-handed adjustment making it easy to suit each user.

Machined from billet aluminum, the unit is powder coated for a durable, lasting finish. Hand assembly ensures that a quality product is shipped to you.

SPECIFICATIONS:

Finish: Gray, black or medical white

Weight capacity: 28lbs (12.7 kg)

Vertical adjustment range: 5"

Keyboard tray size: 20" x 10"

Maximum reach: 46.1"

Minimum profile: 11.8"

Arm swivel at mount: 180°

Screen swivel: 360°

Screen tilt: 50°

VESA interface: 75mm and 100mm

OPTIONS:

- 11" and 20" extension arms
- Available in desk, wall, pole, and wall track mounts
- Several fold-up keyboard tray options available

