

Ultra 500I Wall Track Workstation



Model Number as shown:
UL500I-T36D-KUP-A4-MW
(monitor, keyboard and mouse not included)

ICW

Ultra 500I Wall Track Workstation

Model Number as shown:
UL500I-T36D-KPC-A4-MW

DESCRIPTION:

The Ultra 500I LCD and keyboard mounting system is your entire workstation on a wall track. Unlike the 500 model, the 500I monitor interface is inverted providing a wider range of tilt. Two handles next to the LCD tighten it into position once tilt adjustment is made. The LCD is mounted with two articulating arms which can be extended up to 27" from the wall. This model is designed to be mounted to a 36" wall track, included with the unit.

This model is shown in the drawing with a 20" by 10" liftable HDPE keyboard tray (only in white) with a slide-out mouse tray, which can be folded up when not in use. The keyboard tray on this model is on two articulating arms which can extend it to 46.1" from the wall.

Machined from billet aluminum, the unit is powder coated for a durable, lasting finish. Hand assembly ensures that a quality product is shipped to you.

SPECIFICATIONS:

Finish:	Gray, black or medical white
Weight capacity:	18 lbs (8.16 kg)
Maximum reach:	46.1"
Arm swivel at mount:	180°
Screen swivel:	360°
Screen tilt:	180°
VESA interface:	75mm and 100mm

OPTIONS:

- 19" or 36" wall track
- 11" and 20" extension arms for both keyboard and monitor
- Several fold-up keyboard tray options available

