

Ultra 510 LCD/Keyboard Mount



Model Number as shown:
UL510-W3-KUP-A2-QG
(monitor, keyboard and mouse not included)

ICW

Ultra 510 LCD/Keyboard Mount

DESCRIPTION:

The Ultra 510 LCD Arm Series allows full articulation of the flat panel monitor and keyboard. It has two articulating joints together offering 90° of tilt adjustment with safety stops, plus two locking handle cranks to set positions. The monitor can be adjusted vertically on two stainless steel rails with 4" of change. This system can be mounted with two articulating extension arms, allowing for up to 41" of reach with a keyboard tray. It is widely used in medical and dental applications.

Machined from billet aluminum, the unit is powder coated for a durable, lasting finish. Hand assembly ensures that a quality product is shipped to you.

SPECIFICATIONS:

- Finish: Gray, black or medical white
- Weight capacity: 18 lbs (8.16 kg)
- Vertical adjustment range: 4"
- Maximum reach: 41" w/keyboard
- Stowed profile: 9.5"
- Arm swivel at mount: 180°
- Screen swivel: 360°
- Screen tilt: 180°
- VESA interface: 75mm and 100mm

OPTIONS:

- 11" and 20" extension arms
- Available in desk, wall, pole, and wall track mounts
- Several fold-up keyboard tray options available

